


# WT-Edgecam Interface



Manual

**WinTool Interface 4.7.3 for Edgecam**

The interface enables Edgecam users to find tool assemblies and lists in the *WinTool* database and to transfer them to Edgecam. The interface also generates a *WinTool* tool list with the tools used in the Edgecam NC program.

#### Requirements

- *WinTool* 2011 and newer
- Edgecam 2015 R2 – 2017 R2 – 2018 – 20202.1 - 2021

WinTool AG  
Flüelastrasse 7  
CH-8048 Zurich  
Phone: +41 (0)44 401 00 55  
info@wintool.com  
<http://www.wintool.com>

## Content

Summary .....	3
Job .....	3
Requirements.....	3
Supported Tool Types .....	3
Licensing.....	3
Copyright.....	3
Installation .....	4
Directory Structure .....	4
New Installation.....	4
Updates.....	4
Installing Edgecam Integration Files.....	5
Licensing.....	6
Configurations .....	7
Interface Configuration Window.....	7
Configuration File.....	7
Edgecam Settings.....	10
WinTool Settings.....	13
Getting Started .....	14
Sample Database .....	14
Toolbar .....	14
Importing Tools and Tool Lists.....	15
Tool Path Verification.....	17
Export Tool List to WinTool.....	17
Preparing Tool Data in WinTool .....	18
User Classification .....	18
Machine Types.....	19
Tool ID and Name.....	19
Regular Tools.....	20
Special Tools .....	21
Cutting Conditions .....	23
Known Issues.....	25
Software Structure.....	27
Annex .....	28
Edgecam Tool Types.....	28
History .....	29
Tested with <i>WinTool</i> Demo Database .....	33

## **Summary**

### **Job**

The interface enables Edgecam users to find tool assemblies and lists in the *WinTool* database and to transfer them to Edgecam. The interface also generates a *WinTool* tool list with the tools used in the Edgecam NC program. Cutting conditions and full graphic representations of tool assemblies are supported by the interface.

### **Requirements**

- *WinTool* 2011 and newer
- Edgecam 2015 R2 – 2020.1

### **Supported Tool Types**

A list of supported Edgecam tool types can be found in the chapter [Edgecam Tool Types](#)

### **Licensing**

You need a license code and a license agreement with *WinTool* AG, Switzerland.

### **Copyright**

This documentation as well as the software itself is copyright of

#### **WinTool AG**

Fluelastrasse 7  
8048 Zurich, Switzerland

Phone: +41 (0)44 401 0055

Mail: [info@wintool.com](mailto:info@wintool.com)

Website: [www.wintool.com](http://www.wintool.com)

## Installation

### Directory Structure

WT-Edgecam-Interface 4.3 introduces a clear separation of program files and user data. All user data is centrally placed the [\[Public Documents\]](#) \WT-Edgecam-Interface folder:

User data	New location
Default location of UserModels folder	<a href="#">[Public Documents]</a> \WT-Edgecam-Interface\UserModels
Default location of Exchange folder	<a href="#">[Public Documents]</a> \WT-Edgecam-Interface\Exchange
Configuration files: WT-Edgecam-Interface.cfg WT-MakeList.cfg WT-ToolExport.cfg	<a href="#">[Public Documents]</a> \WT-Edgecam-Interface
License file: License.EWA	<a href="#">[Public Documents]</a> \WT-Edgecam-Interface

**Note:** [\[Public Documents\]](#) on Windows XP is located in [C:\Documents and Settings\All Users\Documents](#)

On newer Windows versions it is located in [C:\Users\Public\Documents](#)

### New Installation

Log on with administrator rights to install the software on a PC.

Install *WinTool* Professional first before you install the WT-Edgecam-Interface.

Download the latest WT-Edgecam software release from [www.wintool.com](http://www.wintool.com) and start Setup.exe.

After successful installation, follow the instructions in chapter [Installing Edgecam Integration Files](#) on the next page.

### Updates

First make a backup of the existing license file **License.EWA** in the Edgecam installation folder (Edgecam 2015 and newer : [\[My Documents\]](#) \[Vero Software" or "Planit"] \[Edgecam version] \Edgecam\cam\PDI\cat-run or

Edgecam 2014 and older : [c:\Program Files\Edgecam\CAM\PDI\Cat-Run](#)) before you update the WT-Edgecam Interface.

The License.EWA contains your license code. If you do not have this file you must contact your WT-Edgecam Interface License supplier and request one (see chapter "Licensing" below).

Download the latest WT-Edgecam software release from [www.wintool.com](http://www.wintool.com) and start Setup.exe.

After successful installation, follow the instructions in chapter [Installing Edgecam Integration Files](#) on the next page.

You are updating from version 4.2.3 or older:

- If the interface was installed in the **same directory** as the previously installed version, the configuration files are automatically moved to [\[Public Documents\]](#) \WT-Edgecam-Interface. Check the interface configuration using the configuration window (see page 11) and the configuration files "WT-MakeList.cfg" and "WT-ToolExport.cfg".
- If you chose a **different directory** for the interface, you must copy the configuration files manually from the previous installation directory to the directory [\[Public Documents\]](#) \WT-Edgecam-Interface
- The default location of the setting [UserModelPath](#) has changed. If you haven't set a [UserModelPath](#) in the interface configuration, in which case the UserModels folder is in the interface installation directory, you must move the contents of the folder to the new default location [\[Public Documents\]](#) \WT-Edgecam-Interface\UserModels.

If you are updating from a Edgecam 2014 or an older version:

Go to Start > All Programs > WinTool > WT-Edgecam-Interface and select "Import license from old location". If a license was found, it will be copied automatically to the new location. If no license was found, copy the License.EWA file manually to [\[Public Documents\]](#) \WT-Edgecam-Interface

Check if the WT-Edgecam configuration is correct using the configuration window (see page 6).

If you update from Version 2.1 or older remove the old tool bar in Edgecam. It will be replaced with a different one.

IMPORTANT NOTE: Now the WT-Edgecam Interface V.4 supports all Edgecam tool types. Please check if you have to re-assign the *WinTool* with the Edgecam tool types (see detailed instructions in the chapter Getting Started)

## Installing Edgecam Integration Files

Edgecam 2015 introduces a new file structure. The import and export files used by the WT-Edgecam-Interface are now placed at a user specific location:

[My Documents]\["Vero Software" or "Planit"]\[Edgecam version]\Edgecam\cam\PDI\cat-run


They are installed automatically during the setup.

You can start the installation manually. This is necessary if they are missing or when a different user is logged in:

- Click on: Start
- Select "All Programs > "WinTool"> "WT-Edgecam-Interface" > "Install Edgecam Intergration Files"

### Version 4.7.2


- Copy the folder «WinTool» from "C:\Program Files (x86)\WinTool\WT-Edgecam-Interface\Riboon to <<current user path>>\Documents\Vero Software\2020.0\EDGECAM\Themes
- Copy the content from "C:\Program Files (x86)\WinTool\WT-Edgecam-Interface\Cat-Run" to <<current user path>>\Documents\Vero Software\2020.0\EDGECAM\cam\PDI\cat-run
- Open Edgecam and select WinTool:



All the buttons should be visible.

## Licensing


The interface does not work without a valid WT-Edgecam Interface license. The following error message appears instead:




You must acquire a license code first.

To license the WT-Edgecam interface, a "license key code" based on the "Physical Address" of your PC's Ethernet adapter is generated. You can find the "Physical Address" of your PC as follows:

1. Click on: Start
2. Select "Run..."
3. Type 'CMD'
4. Enter
5. Type 'Ipconfig /all'
6. Enter



The physical address of your PC will be shown:



Please send this information together with your company name, your personal name, and your phone number to [info@wintool.com](mailto:info@wintool.com) with the subject "WT-Edgecam-Interface License".

You will receive a file called "License.EWA" that contains the license code for your physical address. Copy this file in the public WT-Edgecam-Interface folder [\[Public Documents\]\WT-EdgeCAM-Interface](#)

## Configurations


### Interface Configuration Window

The configuration window lets you easily change the settings of the WT-Edgecam-Interface.

Open the configuration screen in:

Start > All Programs > WinTool > WT-Edgecam-Interface > WT-Edgecam-Configuration

The following screen appears:



<OK> stores all settings. <Cancel> exits the configuration window without saving.

**IMPORTANT:** Set the correct UserModels path for your company directory on the server.

### Configuration File

The configuration window reads and stores settings in the file [WT-Edgecam-Interface.cfg](#) which is located in the "[Public Documents]\WT-Edgecam-Interface" directory.

The file can be edited with the Interface Configuration Window or with a text editor.

Some of these settings will be stored as Windows Registry Variables. The following parameters will be loaded in the Registry Variables when running the software next time.

**Note:** The total length of path and filenames must not exceed 255 characters.

## Output Path

The interface transfers data between *WinTool* and Edgecam and vice versa via exchange data files. The Output Path defines the directory for the data exchanges.

This directory must not be shared by multiple users because the data transferred via this directory is NC project specific and temporary only.


The default settings are:

OutputPath = [Public Documents]\WT-Edgecam-Interface\Exchange\

## Description

In Edgecam the Description is used to better identify tools, the interface makes it configurable how the Description is generated while importing Tool assemblies from WinTool, making imports more flexible. It is up to the user to define a custom naming convention. The interface, however, will provide a default convention which is backward compatible with older Edgecam Interface installations. With the new Edgecam Interface 4.7.3 (and newer) placeholders (put in square brackets) can be used to modify the Description. Most Tool values made in WinTool are supported. A short list of supported placeholders:

*Tools.Nr*, *Tools.TNumber*, *Tools.Comment*, *Tools.Name*, *Tools.MachineNr*, *Tools.Descript*, *Tools.Design*, *Tools.MaskNr*, *Tools.ToolWidth*, *Tools.ToolLength*, *Tools.OldName*, *Tools.MDate*, *Tools.StockState*



Special placeholders with dependent meanings:

- *TNumber* – (without Tools prefix) will become T from Lists if a list is imported, otherwise T from Tools if a tool is imported.

## Important Notes:

- Placeholders have to be put in square brackets.



- Parameter Description is limited by TopSolid to 266 characters.

**Example:**

A setting like

```
[Tools.Nr] - [TNumber] - [Tools.Descript]
```

could be translated to

```
616021 - 0 - End Mill HSS 4x19 4FL
```

if imported via Tool assembly, or to

```
616021 - 123 - End Mill HSS 4x19 4FL
```

when imported via Tool list.

**UserModels Path**

The UserModels directory manages the transfer of tool contour graphics and 3D models including CAM-specific tool models (STL or DXF). *WinTool* links and manages these models and all NC programmers must access and share this data.

The default settings are:

UserModelsPath = [Public Documents]\WT-Edgecam-Interface\UserModels\

If you have multiple NC programmers you must create a UserModels folder on the server and backup the data from time to time.

**Select Cut Data**

If SelectCutData is deactivated (**False**) no cutting conditions are transferred. If this parameter is activated (**True**) cutting conditions for work materials are transferred. By default the transfer of cutting conditions is turned off (**False**).

For tool assemblies, tool lists and machine tools the import uses a different cutting condition selection procedure:


Import	Selection procedure
tool assembly data	The cutting condition window opens and all available cutting conditions can be selected.
tool list data	<p>The interface imports all cutting conditions available for one material only.</p> <p>The material is automatically preselected by the interface if the field material in the WinTool tool list has been filled in.</p> <p>Otherwise the cutting condition window of the first tool in the list will be displayed and a cutting condition must be selected manually. The material for this value will be registered by the interface and is used to preselect the cutting condition for all succeeding tools of the list.</p> <p>If a tool has more than one cutting condition for the same material or if no cutting condition exists for the material, the interface requests to select it manually.</p>

machine tools data	<p>The interface imports all cutting conditions available for one material only.</p> <p>The cutting condition window of the first tool of the machine will be displayed and a cutting condition must be selected manually. The material for this value will be registered by the interface and is used to preselect the cutting condition for all succeeding tools of the machine.</p> <p>If a tool has more than one cutting condition for the same material or if no cutting condition exists for the material, the interface requests to select it manually.</p>
--------------------	---

**Note:** The cutting conditions window appears only if there is at least one cutting condition value stored.


## Edgecam Settings

To activate the WT-Edgecam-Interface buttons, you can use the *WinTool* theme that is installed with the interface:



Alternatively, you can create the buttons and assign them to your theme:

- Click with the right button of the mouse on the toolbar and select **Customise the ribbon**
- Move to **Tools** tab to add the commands.  
[&EDGEUSER] is the keyword to define the Edgecam folder in the user's documents



Add a command for GET, PUT and DEL with the following commands

- **GET:** [&EDGEUSER]\cam\PDI\cat-run\TOOL\_IMPORT.js
- **PUT:** [&EDGEUSER]\cam\PDI\cat-run\TOOL\_EXPORT.js
- **DEL:** [&EDGEUSER]\cam\PDI\cat-run\TOOL\_DELETE.js

### Manage Themes and Ribbon Customisation

Customise The Ribbon ...  
Quick Access Toolbar  
**Tools**  
Import Theme  
Export Theme

Menu contents:


GET  
PUT  
DEL

Command: [;&EDGEUSER]\cam\PD\cat-run\TOOL\_IMPORT.js


Arguments:

Initial directory:


- Move to **Customise the ribbon** tab to create the panel with the commands in the **Machining** toolbar. Select **Machining** then click on **New Panel** and insert **WinTool** in the textbox



- Select **Tools** from the selection then add the commands to **WinTool** panel




- Click on **OK** button then going to **Machining** tab it appears the **WinTool** panel




## WinTool Settings

Go to *WinTool* Tools > Settings > CAM Settings and select the Edgecam interface:



This enables Edgecam in the window Tool Assembly folder CAM:




**Notes:** The settings of the activated CAM interface will be stored in the *WinTool* database (WTData). If you switch your WinTool Professional installation to another database you must activate the Edgecam interface in the new database as well (see chapter Getting Started).

The "Transferred" flag is not used in the WT-Edgecam-Interface.

## Getting Started

### Sample Database


The WT-Edgecam Interface always uses the *WinTool* database currently linked to your *WinTool Professional* installation. To test the interface and get familiar with its functionality, please copy a virgin database (WTData) from your latest *WinTool Professional* installation CD and re-link your *WinTool* to this database:



**Note:** The following chapters refer in general to the sample data in the virgin database.

### Toolbar

The *WinTool* toolbar in Edgecam gives you access to the *WinTool* tool database. The toolbar offers three functions:




- **GET:** Import a single tool or a tool list incl. 3D model and cutting conditions.
- **PUT:** Create a *WinTool* tool list with the tools used in the current Edgecam sequence.
- **DEL:** Delete all data in the Edgecam tool store. This function should only be used if NC programmers must work with *WinTool* tools only.  
*Note: By default the Clear button is activated.*


**\*Note:** The *WinTool* database must always remain the master tool data in the production process to avoid redundancies and errors. It is best practice to delete all tools in the Edgecam toolstore from time to time and refresh the data by importing a current *WinTool* tool list with all standard (or resident) tools you use on the machine.

To disable the clear button, you will have to open the file "`TOOL_DELETE.js`" in the subfolder "[My Documents]\[\"Vero Software\" or \"Planit\"]\[Edgecam version]\Edgecam\cam\PDI\cat-run" of your Edgecam Installation with a text editor.


Add "//" in line 3 and remove "//" in at the beginning of the line 4 in the file and save it.


## Importing Tools and Tool Lists

Select  to import tools from *WinTool* and add them to the Edgecam tool store. The following WT-ToolExport menu will open:





Select the icon for Tool Assembly to import tools individually or for Tool List to load an existing *WinTool* tool list. If you know the tool assembly ID or tool list name, you can fill in the value and hit enter on your keyboard. The tools will immediately be transferred.

Click on  to open the tool classification tree. Select and highlight the desired tool.



There are filters available for machine type, tool data release state, cutting conditions for different materials, and preferred tools. You can also enter commands (> , < , >= , <= ) to filter a list of tools:



The function  turns on combo box selection for the tool values:

DMC	CL...	CR...	CArc	LColl	ID	Descript	Design
50.4	0	0	0	0	500057	BARRA MICROMÉTRICA Ø...	
22.4	0	0	180	70	500058	BMA-003-Ø20-15,5	Inserts CC73-0602??N
36.55	0	0	180	51	500062	CPM-001-C/ Ø36,55	Inserts CC73-0602??N

You can review detailed tool data in the folder tabs Graphic, Data, and Cutting conditions:

Graphic		Data		Cutting conditions	
Diameter (D)	50.4				
Dia step 1 (Da)	0				
Collision Dia (Dx)	0				

If the cutting conditions import function is turned on ([SelectCutData](#) is enabled) in the configuration window the following window pops up and lets you pick a value to be transferred.

Assembly cutting conditions

Tool assembly: 616092 end mill edging R220.69 80mm

DMC	StNr	ap	ae	Dia	z	Vc	fz	S	R	Type	Coolant Type	P	T	Comme
122	1.0570 *	5	40	80	7	226.2	0.08	900	504	Roughing	2 On	5	0	recom
311	1.1545 *	5	40	80	7	158	0.168	629	740	Roughing	2 On	0	0	
712	3.0506 *	5	40	80	7	702	0.203	2793	3969	Roughing	2 On	0	0	

ap	ae	D	z	Vc	fz	S	F	P(kW)	T(Min)
5	40	80	7	226.2	0.08	900	504	5	0

122 General structural steel \*unalloyed more than 500 N/mm<sup>2</sup>

Comments: Roughing 2 On

recommendation SECO

OK Cancel Abort

If you click on "Cancel" it will not transfer any cutting conditions with the tool. "Abort" will stop the entire tool data transaction to Edgecam.


If no Edgecam tool type has been previously assigned to the selected *WinTool* classification, you must do it now. This will map the *WinTool* classification to the Edgecam tool type. Select the correct Edgecam tool type from the selection list.

Select Style:

The current tool doesn't have a valid ToolStyle assigned. Please select one from the List below.

616092 end mill edging R220.69 80mm

- Center Drill
- Spot Drill
- Drill
- Right Hand Tap
- Left Hand Tap
- Reamer
- Bore
- Counter Bore
- Counter Sink
- End Mill
- Sphere Mill
- Chamfer Mill
- Face Mill
- Slot Mill
- Roughing Mill



☐ Store in assigned Tool Class


OK Cancel Abort

If you select "Ignore" to assign to a tool classification, the tool assemblies in this classification will not be transferred at all. This is useful for data that must not be transferred to Edgecam, e.g. measuring equipment.

In most cases it makes sense to assign the mapping permanently to a tool classification. Then you must also check the box "Store in assigned Tool Class" (recommended).



To import a tool list select the list function, mark the list in the window below and hit <OK>:



## Tool Path Verification


For “material removal simulation” the tool geometry parameters of the cutters will be transferred from *WinTool* to Edgecam. This allows Edgecam to calculate the material removal.


For “collision simulation” the WT-Edgecam-Interface creates and imports a 3D tool representation. For rotating tools *WinTool* creates a tool contour with the Shape-Generator and imports it to Edgecam (*WinTool* supports also manually created contours). For non-rotating tools *WinTool* assembles STL-components to a STL-tool assembly and imports it to Edgecam.

## Export Tool List to WinTool

Once a NC-Program has been finished in Edgecam, the list of all the tools used in the NC code must be stored back to *WinTool* so that the job can be further processed in G-Code verification, production planning, purchasing, storage, presetting, and machining.



Use the function  to create a tool list of the tools that have been used in the Edgecam sequence. The following window will open:



**Note:** Only tools that are used in the Edgecam sequence (NC program) will be considered in the *WinTool* tool list. An already existing tool list with the same name will be overwritten. The sequence of the assemblies in the tool list will be the same as the sequence of the operations in the Edgecam operations manager.

Select OK to store the information in the *WinTool* database.

## Preparing Tool Data in WinTool

Before starting to record your tool data in *WinTool*, read the following chapter carefully! The interface software can only work if the data has been entered fully and correctly.

For the WT-Edgecam-Interface to work properly *WinTool* component and assembly data must be recorded correctly. *WinTool* resellers offer training courses to make sure that you are building a high-quality tool database that is fit for engineering requirements.


However, the following points are prerequisite for the WT-Edgecam-Interface to work and will be described in detail in the chapters below:

- Each *WinTool* classification must be assigned to the corresponding Edgecam tool type.
- Each tool assembly must be linked to a *WinTool* Machine Type.
- Each tool assembly must have a "namegiving" component.
- The tool geometry must be recorded in *WinTool* with the correct Tool Type and Outline (for details please refer to the *WinTool* Professional documentation)

## User Classification

Each tool classification in *WinTool* must be assign to the corresponding Edgecam tool type. In *WinTool* select Settings > Class, then select a classification. In the data field "Note" you can assign the corresponding Edgecam tool type.

For the classification "212 - end mill roughing" assign the tool type /EC201.



Edgecam tool types are listed in the Annex of this manual.


## Machine Types

In order to create tool assemblies in *WinTool* you must record Machine Types in *WinTool*. Record for each machine adapter type (CAT40, HSK63A, Capto etc.) a Machine Type in *WinTool* (see *WinTool* Help).

**Note:** Tool assemblies must be assigned to a *WinTool* Machine Type or they cannot be imported in Edgecam.


## Tool ID and Name

Each tool assembly record in *WinTool* gets a unique numeric Ident No assigned.




Each *WinTool* tool gets a unique tool name during Edgecam import. The tool name is a combination of the *WinTool* Ident No and the Description. Example:  
**616093 face mill R220.43 100mm**

**Note:** During import to Edgecam the tool assembly data is generated from its *WinTool* component data. One of the components must be marked as “Namegiving” or *WinTool* cannot assign a name to the tool assembly in Edgecam and import it.




## Regular Tools

*WinTool* considers “Regular Tools” - as opposed to “Special Tools” - all tools that have a Outline and are supported by the Shape-Generator (See also *WinTool* Shape-Generator Manual for details):



According to these Outlines the tool geometry must be filled in in *WinTool* completely. Only then assemblies can get transferred to Edgcam correctly. You can verify the tool contour directly in *WinTool*:



## Special Tools

If a contour of a tool assembly or a STL model cannot be 100% automatically processed by *WinTool* it is considered a “Special Tool”.

### Managing Special Tools


Special tool graphics/models must be stored in your *UserModels* directory and they must have the *WinTool* tool assembly Ident No as the name (eg. 616099.dxf or 616099.stl).

Then the WT-Edgecam Interface will find the model during tool data import and transfer the model as well.


### Special Tool Contour DXF

If you have a special tool - and cannot find a suited Outline in *WinTool* - then you need to create a special contour manually. However, the following works only for special *tool holders* for collision check, but not for *special form cutters* for material removal simulation.

In order to create a special contour use first the *WinTool* Shape-Generator to create a contour close enough to your special tool. Then customize the contour with *WinVector* or *Edgecam*. You must use the layers CUT, NOCUT, and SHANK:




Save the DXF-Contour in your *UserModels* directory with the Ident No as the file name (see chapter above). Then you must set the User Model flag in the *WinTool* tool assembly window:




**Note:** If the User Model flag is active the *WinTool* Edgecam-Interface will not run the Shape-Generator to produce the contour file, instead it will import the customized file available in the *UserModels* directory with the same Ident No as name.

## STL Tool Models



STL tool component models can be linked in the *WinTool* component window. The file name must be the same as the Item No.



The scaling must be 1:1, metric or imperial according to the *WinTool* tool component settings, and the orientation of the STL component models must be as follows:



Then *WinTool* 3D-STL Generator creates a STL tool assembly from the component STLs automatically:




**Note:** The STL tool assembly must not include the inserts. The STL serves only for collision checks. For material removal simulation Edgecam will use cutter geometry parameters.

Save the STL model in your **UserModels** directory with the Ident No as the file name (see chapter above).

The WT-Edgecam-Interface imports *WinTool* STL models, scales them according to the Edgecam project settings (inch or metric) and positions them according to the Edgecam design (rotation of z-axis).


The cutting orientation (1 to 9) will be transferred by *WinTool*:




## Cutting Conditions


Cutting conditions stored with a *WinTool* tool assembly are transferred automatically to the Edgecam Tool Store.

You can select a cutting condition during the data import if the setting **SelectCutData** has been enabled (see Configurations).





The coolant type will be transferred.



Off -> 0  
Flood -> 4,5,8,9  
Mist -> 3  
Air -> 1


**Note:** Currently the WT-Edgecam Interface imports all cutting value if multiple values have been stored and [SelectCutData](#) has been disabled.



## Known Issues

### Single tool assembly doesn't import ident no. as layer name

The layer appears to be incorrect in the tool dialog, but it is set to the tool assembly ident no. when you select OK.



### "Invalid License" message after interface update


Go to Start > All Programs > WinTool > WT-Edgecam-Interface and select "Import license from old location".

### WinTool Theme doesn't exist in Edgecam and/or folder "<My Documents> \<Edgecam> \cam\ PDI\ cat-run\" is empty

Make sure your user has write access to the folder "<My Documents> \<Edgecam>" and the subfolders. Then, go to Start > "All Programs > "WinTool" > "WT-Edgecam-Interface" and select "Install Edgecam Intergration Files" to install the theme and the interface files.

### Holders are not displayed in ToolStore and simulation



In the "Applications" section of the Edgecam launcher, open "Settings". Then, open "File Locations".



In the category "ToolStore Support Folder", set the Path. It depends on the settings in your company, but generally, either <USER>\cam\tstore\ or <PUBLIC>\cam\tstore\ must be set. Confirm with OK.

Category	Path
Code Generators	<USER>\cam\machdef,<NETWORKLOCATION>\cam...
ToolStore Support Folder	<USER>\cam\tstore\
Master Strategy Folder	<USER>\Themes\default\strategy

## Registry key is invalid

```

1 <?xml version="1.0" encoding="utf-8"?>
2 <configuration>
3   <configSections>
4     <sectionGroup name="applicationSettings" type="System.Configuration.ApplicationSettingsGroup, System, Version=4.0.0.0, Culture=neutral, PublicKeyToken=b77a5c561934e089">
5       <section name="WT2EC.Properties.Settings" type="System.Configuration.ClientSettingsSection, System, Version=4.0.0.0, Culture=neutral, PublicKeyToken=b77a5c561934e089" basePath="applicationSettings"/>
6     </sectionGroup>
7   </configSections>
8   <applicationSettings>
9     <WT2EC.Properties.Settings>
10       <setting name="LicenseFile" serializeAs="String">
11         <value>C:\Users\Public\Documents\WT-Edgecam-Interface\License.ewa</value>
12       </setting>
13       <setting name="EdgeMacroImport" serializeAs="String">
14         <value>Tool_Import.js</value>
15       </setting>
16       <setting name="EdgeMacroDelete" serializeAs="String">
17         <value>Tool_Delete.js</value>
18       </setting>
19       <setting name="EdgeTmpFile" serializeAs="String">
20         <value>TmpFile.js</value>
21       </setting>
22       <setting name="GraphicConverterApp" serializeAs="String">
23         <value>DXF2CSV.exe</value>
24       </setting>
25       <setting name="EdgeDistributor" serializeAs="String">
26         <value>Hexagon</value>
27       </setting>
28       <setting name="EdgeDbRegPath" serializeAs="String">
29         <value>HKEY_CURRENT_USER\Software\{0}\Edgecam\{1}\Location</value>
30       </setting>
31       <setting name="EdgeDbRegKey" serializeAs="String">
32         <value>Tool Store Server</value>
33       </setting>
34       <setting name="EdgeDirRegKey" serializeAs="String">
35         <value>Tool Store Directory</value>
36       </setting>
37       <setting name="EdgeHoleHolderDir" serializeAs="String">
38         <value>HolderGraphics\Hole</value>
39       </setting>
40       <setting name="EdgeMillHolderDir" serializeAs="String">
41         <value>HolderGraphics\Mill</value>
42       </setting>
43       <setting name="EdgeTurnHolderDir" serializeAs="String">


```

You have to edit the WT2EC.exe.config file and set the **EdgeDistributor** value to **Vero Software**.

The table below reports which value to set according to the version:


Value	Version
Planit	2014R2 to 2015R1
Vero Software	2015R2 to 2020.0
Hexagon	2020.1 to last version (2021.0)

## Software Structure



## Annex

### Edgecam Tool Types



Edgecam-Suffix	Edgecam Tool Type	WT-Edgecam Interface Support
201	Endmill	yes
202	Bullnose	yes
203	Tap	yes
204	Drill	yes
205	Taper	yes
206	Turn	yes
207	Bore	yes
208	Groove	yes
209	Thread	yes
206	Turn	yes
210	Parting Off	yes
211	T-Slot	yes
212	Lollipop	yes
213	Ballnose	yes
214	SlotDrill	yes
215	Facemill	yes
216	Ream	yes
217	HoleBore	yes
218	Countersink	yes
219	CentreDrill	yes
220	SpotDrill	yes
221	BackBore	yes
222	Threadmill	yes
223	Probe	yes

#### WinTool specific type:

00	Ignore	-
----	--------	---

## History

### 4.7.3

- ✓ Compatible with WinTool 2020.3.1
- ✓ Tool Import Improvements
- ✓ Indexable Thread Mills are now correctly Imported
- ✓ Updated Manual

### 4.7.2

- ✓ Compatible with Edgecam 2021
- ✓ General Improvements

### 4.7.1

- ✓ Compatible with Edgecam 2020.1

### 4.7.0

- ✓ Compatible with Edgecam 2020

### 4.6.1

- ✓ Improved license file location definition [WT-2281]
- ✓ Fixed reamer diameter [WT-2287]
- ✓ Fixed import of bullnose mills [WT-2288]
- ✓ Improved import of thread mills [WT-2397]
- ✓ Fixed export of thread mills [WT-2398]

### 4.6.0

- ✓ Compatible with Edgecam 2015 R2 - 2018 R1
- ✓ Fixed wrong tool type importation for /EC211 code [WT-1959]
- ✓ Fixed wrong tool type importation for /EC218 [WT-1957]
- ✓ Added the importation of coolant settings [WT-1960]
- ✓ Fixed wrong cutter position [WT-2083]
- ✓ Uses the quadrant information to orientation of the cutting in the turn tools
- ✓ Fixed wrong data for holder offsets [WT-2084]
- ✓ Fixed the problem which generates simulation exception for probe tools [WT-2175]
- ✓ Fixed representing of "Fine-Boring Tools" [WT-2181]
- ✓ Diameter is missing for several tool types [WT-1958]
- ✓ General improvements

### 4.5.4

- ✓ Compatible with Edgecam 2015 R2 - 2017 R2
- ✓ Added support for Probe class (/EC223)
- ✓ Importing tool assembly machine type into holder type
- ✓ Importing cutting conditions with material data to enable automatic import into operation
- ✓ Corrected import of diameter of hole bore tools
- ✓ Corrected freeze of Edgecam when importing tools

### 4.5.3

- ✓ Compatible with Edgecam 2015 R2 - 2017 R1

### 4.5.2

- ✓ Compatible with Edgecam 2014 R2 - 2016 R2

#### 4.5.1

- ✓ Improved turning tool import

#### 4.5

- ✓ Compatible with Edgecam 2014 R2 -2016 R1
- ✓ Compatible with *WinTool* 2011 – 2015
- ✓ Added support for Threadmill class (/EC222)
- ✓ Corrected layer name import
- ✓ Corrected import of Taper class for tools with a tip

#### 4.4

- ✓ Compatible with Edgecam 2015 R2

#### 4.3

- ✓ Compatible with Edgecam 2012 R2, 2013 R1/R2 and 2014 R1 with Service Update 3
- ✓ Compatible with *WinTool* 2011 – 2014
- ✓ Separated program files and user data
- ✓ Included newest version of WT-MakeList (see detailed changes in WT-MakeList manual)
- ✓ Included newest version of WT-ToolExport:
  - Saving selection state of "preferred only" filter
  - Improved readability with high DPI settings
  - Compatible with *WinTool* 2014
- ✓ Single tool assembly import: Transferring ident-no for t-no if "T-No=Ident No" is activated in the machine type

#### 4.2.3

- ✓ Included newest version of WT-MakeList due to issue with SQL Server

#### 4.2.2

- ✓ Compatible with Edgecam 2013 R1/R2
- ✓ Compatible with *WinTool* 2013, 2012 and 2011
- ✓ Included newest versions of WT-ToolExport and WT-MakeList module
- ✓ Removed error message after import of tool list
- ✓ WT-ToolExport:
  - Resizable search windows

#### 4.2

- ✓ Compatible with Edgecam 2013
- ✓ Compatible with *WinTool* 2012 incl. new Shape-Generator (Non-cutting Dia)
- ✓ Brackets in tool name will be removed now
- ✓ "Through Coolant" Flag gets imported
- ✓ CLEAR function is configurable (on/off)
- ✓ Support of STL models with standard *WinTool*/Vericut axis orientation
- ✓ Removed error message when aborting import operation
- ✓ Tool selection window size is adjustable now
- ✓ Z gauge correctly imported for INCH tools

#### 4.1

- ✓ Compatible with *WinTool* 2011
- ✓ Inch tool assemblies are imported correctly
- ✓ Tool assembly description is now Tools.Nr instead of Tools.Nr + "\_" + Descript
- ✓ Importing D and H values of tool assemblies from tool lists

- ✓ Added tool type "Ignore" (/EC00) for tool assemblies that must be ignored on transfer
- ✓ Improved error handling
- ✓ Included newest versions of WT-ToolExport and WT-MakeList module
- ✓ WT-ToolExport:
  - Start-up time with large databases is quicker
  - Selected work material and coolant type are displayed
  - "Current dataset"/"Total datasets" is now displayed above the tool/list/ table

## 4.0

- ✓ Simplified setup procedure
- ✓ New licensing method (all updates require a new license file)
- ✓ Using *WinTool* XML exported file standard (WT-CAM-InterfaceApp v1.1)
- ✓ Support / data transfer to Edgecam Tool Store
- ✓ All the calculations are done in program (and no more in the PCI files)
- ✓ Management of multiple cutting conditions per tool
- ✓ Function to delete tools in the active Edgecam database (Tool Store)
- ✓ Tool assembly selection window with improved tool data display
- ✓ New tool assembly search filters (release state, combo box)
- ✓ Enhanced MakeList module (V.3.8)
- ✓ Fix STL position in grooving tools
- ✓ Fix STL size for some thread tools
- ✓ Revision of manual

## 2.3.4

- ✓ Possibility to create a turning Tool without STL file

## 2.3.3

- ✓ Different colors for importing Tools

## 2.3.2

- ✓ Possibility to import up to 300 tools from one tool list

## 2.3.1

- ✓ Added fields SumArcInfluenceZ, InscribedCircle and InsertThickness for turning tools

## 2.3

- ✓ Endmills with tip angle=0 are imported correctly
- ✓ Possibility to specify a cutting condition for a tool assembly during transfer
- ✓ User is asked which Edgecam tool type belongs to a tool assembly during transfer, if it is not correct or missing
- ✓ Order of tool assemblies in Edgecam is preserved when they are transferred back into a tool list in *WinTool*
- ✓ Tool assembly length is transferred to Z Gauge field in Edgecam
- ✓ User models are not deleted when new a tool list is created
- ✓ Using correct character-set to support Umlauts (ä,ö,ü...)

## 2.2

- ✓ STL supported

## 2.1.2

- ✓ Turning Tools supported
- ✓ Error handling for when no isCutter and no isNameGiving component in tool
- ✓ Default export / support of Tool Lists





## Tested with *WinTool* Demo Database

### Milling

616103	spot drill	204
616141	center drill	219
616021	end mill finishing	201
616090	face mill	215
616089	face mill	215
616096	square shoulder cutter	201
616088	chamfer mill	201
616102	disc mill	205
616001	tap metric	203
616057	tap metric blind hole	203
616140	thread mill	222
616138	reamer cylindrical	216
616143	countersink	201

### Turning

636104	turning tool outside	206
636106	turning tool outside	206
636107	turning tool outside	206
636109	turning tool inside	206
636111	turning tool outside	206
636112	turning tool outside	206
636118	turning tool outside	206
636120	turning tool outside	206