

# **WinTool Interface for Esprit EDGE**

**Release 1.1.0 for Esprit EDGE 2024.3 Hotfix 3 (2024.3.2439.1999)**

## **History**

### **1.1.0**

#### **New features, improvements & changes**

- Compatible with WinTool 2024.3
- Compatible with Esprit EDGE 2024.3 Hotfix 3 (2024.3.2439.1999)
- Added support to use CICodes from machine setup in tool list export (WT-Put)
- Improved tool assembly import (tool lists) with mounting on the turret and station defined in WinTool
- Improved tool import for
  - Lathe Turning (/ET137)
  - Mill Drill (/ET156)
  - Mill FaceMill(/ET164)
  - Mill Chamfer (/ET266)
  - Mill CornerRoundMill(/ET267)
  - Mill DoveMill (/ET268)
  - Mill Thread (/ET269)

#### **Known issues**

- Holders (Adaptive Item) file reference disappear after opening properties. As a workaround the file can be set manually. After setting it manually it does not disappear anymore.
- Wrong orientation of inserts in Turning tools with a neutral tool holder (/ET173)

### **1.0.0**

#### **New features, improvements & changes**

- 1<sup>st</sup> release of the Esprit EDGE Interface

#### **Known issues**

- Holders (Adaptive Item) file reference disappear after opening properties. As a workaround the file can be set manually. After setting it manually it does not disappear anymore.
- Wrong orientation of inserts in Turning tools with a neutral tool holder (/ET173)